



# HOW TO APPLY THE VINYL RAX CD HOLDERS.

1




CLEAN SURFACE WITH RUBBING ALCOHOL. DO NOT USE HOUSEHOLD CLEANERS.

2




REMOVE BACKINGS ON DOUBLE SIDED TAPE. LEAVE A MINIMUM OF 100MM GAP BETWEEN BRACKETS.

3




PLACE THE BOTTOM VINYL RAX CD HOLDER ONTO YOUR CHOSEN LOCATION. USE LEVEL TO ENSURE IT IS STRAIGHT. **PRESS FIRMLY.**

4



PLACE CD ON THE BOTTOM VINYL RAX CD HOLDER THAT IS SECURED TO THE WALL.


5



PLACE THE TOP VINYL RAX CD HOLDER IN PLACE ONCE THE CD IS IN THE BOTTOM HOLDER.


**CHECK BRACKETS ARE SECURE BEFORE USE**

6



PUSH THE TOP VINYL RAX CD HOLDER BACK TO FIX TO THE WALL. **PRESS FIRMLY.**

7



TO REMOVE. LIGHTLY PRESS THE BOTTOM OF THE STRIP AND GRAB TAB, STRETCH SLOWLY STRIAIGHT UP ALONG THE WALL UNTIL STRIP RELEASES FROM WALL.

8



NEVER PULL THE STRIP TOWARDS MM, ALWAYS PULL STRAIGHT UP.

DO NOT HANG OVER BEDS OR USE ON WALLPAPER. MAY NOT ADHERE WELL ON VINYL SURFACES. FOR INDOOR USE ONLY. APPLY TO SURFACES BETWEEN 10°C - 40°C. WAIT A MINIMUM OF 28 DAYS AFTER PAINTING TO APPLY.

**VINYL RAX**  
VINYL RAX.COM.AU